

iSensor: configure control board

When the control board is replaced on the iSensor, a parameter related with the intelligent sealing must be configured.

Mind: On models iSensor Medium table top, this configuration is not necessary.

Mind: During the process, the lid must be open.

Enter the test mode:

- 1) Unplug the machine
- 2) While pressing the knob, plug the machine
- 3) Using the knob, choose **CLEAN** mode. Display shows **E-**
- 4) Then, press the knob during 10 seconds. Display shows **F0**.
- 5) Then, press the knob during 3 seconds. Display shows **5** (by default).
This value must be set up according the following table:

Table top iSensor		Food Stand iSensor	
Model	Value	Model	Value
Small (TTSXXXXX)	3	Small (FSSXXXXX)	7
Medium (TTMXXXXX)	5	Medium (FSMXXXXX)	9
Large (TTLXXXXX)	7	Large (FSLXXXXX)	9

- 6) Confirm and quit by pressing the knob during 2 seconds.

iSensor: configure option EXTERNAL GAS

Since the external gas is an optional function, it is necessary to configure the board to activate or deactivate it.

It is done on the hardware of the control board, so it must be configured when replacing the control board.

Without GAS



With GAS

