

TECHNICAL UPDATES

Washing pumps

• Starting from February 2014, we've completed the upgrade of our range of dishwashers with a new series of washing pumps.

To install the new pumps on machines with the previous version it is necessary to make some small modifications which have been summarized in the following table:

| | | | | Installation of the new pump on the machine with the previous model | | |
|----------------------|------------------|----------|-----------------|--|---|---|
| Machine model | Standard Voltage | Old code | New code | Mechanical fixing | Hydraulic connection | Electric connection |
| D 35 dgt D 45 dgt | 230V/50Hz | 00202486 | 20160062 | It is necessary to drill a hole Ø 7 in the frame to stabilize the pump in the event that the machine has to be moved. | If the machines is equipped with a water-softener, shorten the inlet hose or request code 00013827 rev.1 or superior. | - |
| D 85 dgt | 230V/50Hz | 00002500 | 20160063 | It is necessary to bend or remove the tab on the frame to install the pump. | - | - |
| D 120 dgt | 400V/3/50Hz | 00002520 | 20160061 | It is necessary to drill a hole on the original support or replace it with the support code 00018280 (to be ordered separately). | - | Replace original pin connectors with round connectors D4 on cable 23 + N connected to the pump motor. |
| C 34 dgt | 230V/50Hz | 00002500 | 20160053 | Replace the original support with support code 00019537 (to be ordered separately). | Replace pipe code 00019137 with pipe code 00004060 (to be ordered separately). | - |
| C 44 dgt | 230V/50Hz | 00002513 | 20160053 | Replace the original support with support cod. 00019537 (to be ordered separately). | Replace pipe code 00018312 with pipe code 00019136 (to be ordered separately). | Add female faston connector on cables 37 - 38 connected to the pump motor. |
| C 66 dgt | 400V/3/50Hz | 00002520 | 20160061 | It is necessary to drill a hole on the original support or replace it with the support code 00018280 (to be ordered separately). | - | Replace original pin connectors with round connectors D4 on cable 23 - N connected to the pump motor. |

Note: The codes of the pumps refer to the power of the basic version of the machine.

For other versions, please contact our sales department and / or technical support team.

WWW.ELFRAMO.IT

As customer of Elframo, we are happy to send you this newsletter.
If you do not wish to receive this communication anymore, please
send a blank message with subject: CANCEL to service@elframo.it



elframo®